Register your product and get support at

www.philips.com/welcome

Indoor wireless headphones

SHC5102

EN User manual

PHILIPS


A
1
2
3
4
5
AAA
AAA


B
PHILIPS
PHILIPS
PHILIPS


C


D


E


F
PHILIPS
ON/OFF


G


H
CHANNEL
1
2
CHANNEL
1
2

Contents

1 What's in the box 4

2 Get started 5

3 Product version table 6

1 What's in the box

1) 2 x Headphones	2) Transmitter
3) AC/DC adaptor	4) Antenna tube
5) 4 x AAA rechargeable NiMH batteries (SBC HB550L)	

2 Get started

Note

- Before using the headphones for the first time, charge the supplied batteries for at least 10 hours.
- **Only use Philips rechargeable shortened sleeve NiMH batteries with your headphones. Other types of rechargeable batteries cannot be charged with this system.**
- **AAA alkaline batteries can be used to operate the headphones, but cannot be charged with this system.**
- If the volume of the audio source is insufficient, the transmitter automatically turns off.

1 Install/Replace supplied batteries (Fig. B).

2 Install the antenna tube into the transmitter (Fig. C).

3 Power on the transmitter (Fig. D).
   ↳ Red LED is on when audio source is connected.
   ↳ Red LED blinks if no audio source is connected for two minutes.
   ↳ Red LED is off if no audio source is connected for four minutes.

4 To charge the headphones, connect the charging cable with the headphones (Fig. E).
   ↳ Headphones: red LED is off during charge.
   ↳ Transmitter: green LED is on during charge and is off when headphones are fully charged.
   When one headphone is during charge, another one can still be used.
   ↳ Transmitter: both read and green LED are on.

5 Power on the headphones and red LED is on (Fig. F).

6 Connect the audio device with the transmitter (Fig. G).
   ↳ Green LED is on when it is connected.

Tip

- If there is interference, tune the transmitter and the headphones to the same channel (Fig. H).

3 Product version table

Version / Region	Adaptor type number	Input voltage / frequency	Output voltage	Carrier / Reception frequency	
				Channel 1	Channel 2
/10 Europe	SVV-005-080-020-A2	100-240V / 50/60Hz	8V 200mA	863.5MHz	864.5MHz
/05 UK	SBH-005-080-020-A2	100-240V / 50/60Hz	8V 200mA	863.5MHz	864.5MHz

For further product support, please visit **www.philips.com/welcome**

© 2010 Koninklijke Philips Electronics N.V.
All rights reserved.
SHC5102_UM_10_V1.0

CE 0197

100% recycled paper